

# USER GUIDE



## VR PRIMUS

Bluetooth controller  
for Google Cardboard VR apps



**Recommended for Android smartphones**  
Find information for iPhone under "Notes"

[www.vrprimus.com](http://www.vrprimus.com)


## Connect controller with smartphone



1. Insert batteries  
(2x AAA batteries with 1.5V, not included)
2. Press power button until blue LED blinks  
(controller is ready to connect)
3. Connect to smartphone via bluetooth  
(Controller bluetooth name: VR-PARK)

## Mouse mode (only Android Smartphones)

The mouse mode activates the mouse pointer of the smartphone. This allows you to click objects in VR apps with the click button of the controller.



## Game Mode (only Android Smartphones)

The game mode allows the control of selected VR games, e.g. InMind VR.

Activate the vertical or horizontal mode depending on whether you want to hold the controller horizontally or vertically.

Activate  
vertical mode:  
@+C



Activate horizontal  
mode: @+B



## Notes

**Turn off controller:** Press power button until blue LED blinks.  
**Game mode:** This mode deactivates mouse mode. Not all VR games support the game mode.

**iPhone:** Controller doesn't work with VR/Cardboard apps due to system restrictions of the iPhone (iPhone has no mouse function). Only media control (Volume, Play, Pause, Forward, Back) is available. Activate iPhone media mode: @+A.

### Help with connection problems:

1. Disconnect controller from smartphone via bluetooth configuration on the smartphone.
2. Remove batteries from controller.
3. Turn off smartphone (not only restart) and turn it on.
4. Turn off smartphone wifi.
5. Connect controller with smartphone via bluetooth.

**You have questions, ideas or suggestions?**  
Please email us at [service@vrprimus.com](mailto:service@vrprimus.com)